



411 West Congress St., Maple Lake, MN 55358 Toll Free 877-466-8837 www.wavearmor.net

Plastic Ladder Instructions

Tools needed

9/16" socket and ratchet

Parts list

1 – Plastic ladder
2 – 3/8" x 1 3/4" bolt
2 – 3/8" x 2 1/2" bolt
4 – 3/8" washers

1. Ladder may be placed on either side of the raft in the indented area.
2. Align the ladder with the threaded inserts in the raft.
3. Insert the 3/8" x 2 1/2" bolts and a washer in the top holes of the ladder. Thread the bolts into the raft inserts part way. Do not tighten until all bolts are aligned and inserted including the front.
4. Insert 3/8" x 1 3/4" bolts and a washer into the holes on the front side of the ladder. Once all the bolts are aligned they may be tightened up. Do not overtighten the bolts as they can crush the plastic.

